
## **COOKTOP PARTS**

For Models: RF265LXTQ0, RF265LXTB0, RF265LXTT0, RF265LXTS0, RF265LXTY0 (White) (Black) (Biscuit) (S.Steel) (Universal Silver) 30" ELECTRIC CERAN FREESTANDING RANGE SELF CLEAN CONVECTION OVEN 4 6 Literature Parts 5


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus No.	. Part No.	DESCRIPTION
1	9762978 9762996 9757143 9757142	Literature Parts Owner's Manual Tech Sheet Installation Instructions Template, Anti-Tip English/French English/Spanish Brochure, Tips Safe Cooking	3	8273994	Black	4 5 6 7 8	8272791 3196169	Spring, Locator

# **CONTROL PANEL PARTS**



Illus No.		DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus No.		DESCRIPTION
1		Endcap	4		Switch, Infinite	10	8272473	Cover, Rear
	W10009040			9758060	Left Front (Dual)	11		Control, Range
	W10009050	White Right Hand		3148951	Left Rear		W10114376	White
	W10009080	Black Left Hand		3148951	Right Rear		W10114377	Black
	W10009090	Black Right Hand		9758060	Right FronT (Dual)		W10114378	Biscuit
	W10009060	Biscuit, LH	5		Light, Indicator	12	3196178	Screw
	W10009070	Biscuit, RH	6		Lens, Light	13	9757609	Nameplate
2	9762095	Bracket, Console	7		Knob, Infinite (4)	14	3400882	Screw
3		Panel, Control		9761962	. ,	15	8273564	Clip, Cover
	W10117552	White		9761964	Black	16		Screw
	W10117555	Stainless Steel		9761963	Biscuit		3196166	White
	W10117554	Black	8	8523280	Shield, Heat		3196168	Black
	W10117553	Biscuit	9		Brkt, Mntg EOC			


## **CHASSIS PARTS**




# **CHASSIS PARTS**

Illus. No.	Part No.	DESCRIPTION	Illus No.		DESCRIPTION	Illus No.	. Part No.	DESCRIPTION
1	9761300	Vent Tube Asmbly	16	W10058460	Foot, Rear (2)	36	9758238	Retainer, Side (2)
2		Support, Corner LR	17	3195987	, , ,	37		Brkt – Mounting
3		Panel, Side (2)	18		Rod – Dr Switch	38		Latch, Door
_	8053830		19		Support, Oven (2)	39		Rod, Latch
	8053832		20		Bracket, Service	40		Latch Asy, Rear
	8272519	Biscuit	21		Block, Terminal	41		Spacer, Door
4	W10010350	Seal, Oven Flange	22		Back, Main	42	3196169	
5		Seal, Oven Door	23		Switch, Door	43		Cover, Box
6	9757340	Element, Broil	24		Light Socket Assy	44		Screen - Catalyst
7	9758541	Element, Bake	25		Bulb, Oven Light	45		Screw (2)
		(Hidden)	27		Sensor, Oven	46	112432	
8	3195736	Support, Front (2)	28	3196179		47		Insulation
9	3196548	Fuse, Thermal	29	3196178	Screw	48	9761512	Clip, Mounting
10	9759785	Glide, Drwr Top	30	3400016	Screw			
11	3196037	Foot, Front (2)	31	3196172	Screw	INS	ULATION	
12		Frame, Front	32	W10031780	Screw			
		(Not Serviced)	33	W10067840	Screw		8272616	Insulation, Wrap
13	8054068		34	3196168	Screw			Insulation, Back
14		Clip, Panel (6)	35	3196174	Screw		8272613	Insulation, Vent
15	9760314	Rail, Base (2)						

## **DRAWER & BROILER PARTS**



## **DOOR PARTS**



Illus. No.	Part No.	DESCRIPTION	Illus No.		DESCRIPTION	Illus No.		DESCRIPTION
1	9761975 9762394 9762391	Stainless Model	9 10	9761493	Retainer, Insul. Hinge, Door (2) White,Black,Bisc. Stainless Model	13 14	3196160 8523175 8523177	Trim, Lower White
2 3	9761976 3196164 9761982	Screw Handle, Door	11	W10075980 W10075990 W10076000	Black	15 16		Stainless Model Clip, Glass (4)
4			12	8523166	Stainless Steel Trim, Side White Left Hand White Right Hand	17 18 19 20	3196165	Clip, Dr Mntg (2)
5 6 7 8	8522414 9758162 3186289	Seal, Window Glass, Inner (2) Frame, Glass Insulation, Door		8523171 8523165 8523173		21		Strap, Door

### **OPTIONAL PARTS**

For Models: RF265LXTQ0, RF265LXTB0, RF265LXTT0, RF265LXTS0, RF265LXTY0 (White) (Black) (Biscuit) (S.Steel) (Universal Silver)

Illus. Part No. No. DESCRIPTION

Following Parts Not Illustrated

### SPLICING WIRES--25FT.

### **LENGTH**

242828 Wire, Black 12 Ga. 150° c 242821 Wire, Blue 14 Ga. 150°c 242822 Wire, Brown 14 Ga. 150°c 242830 Wire, Brown 14 Ga. 200°c 242823 Wire, Green 14 Ga. 150°c 242824 Wire, Orange 14 Ga. 150°c 242825 Wire, Red 14 Ga. 150°c 242831 Wire, Red 14 Ga. 200°c 242827 Wire, Yellow 14 Ga. 150°c

#### **REFINISHING MATERIAL**

799832 Kit, Porcelain Repair (White) 242756 Touch–Up Self–Clean(1/2 Pt)

261582 Grease

Illus. Part
No. No. DESCRIPTION

#### **INSULATION**

240132 Insulation, Fiberglass (2–1/2" x 22" x 120")

### PAINT, TOUCH-UP (1/2oz.)

72017 White 4392899 Biscuit 511873 White Porcelain (2 Oz.)

## PAINT, PRESSURIZED SPRAY

(12 oz.)

350930 White 4392901 Biscuit 285006 Superior Black 206922 Primer (White)

### PAINT, BULK (1 qt.)

799344 White (Uncut) 4392900 Biscuit (Uncut)

#### **ACCESSORY PARTS**

241430 Foil, Aluminum Oven (18" x 25') 3184478 Cleaner, Glass Illus. Part
No. No. DESCRIPTION

#### **ANTI-TIP KIT**

W10017440 Anti-Tip Kit

#### **WIRING HARNESS PARTS**

### Following Parts Not Illustrated

W10115055 Harness, Wire
(Cooktp Lft Dual)
W10114894 Harness, Wire
(Cooktop Right)
9762951 Harness, Wire
(Main)
9762428 Harness, Wire
(Sensor/Dr Switch)
8523279 Wire, Ground
313660 Clip, Ground Wire
3196154 Screw
3196173 Screw, Grnd Wire